

How to measure for your curtains:

Please always measure to the nearest 5mm increment

Example:

1000mm, 1255mm, 1485mm, 1600mm, 1845mm, 2235mm etc

There are two ways to install/measure you curtains:

- Top Fix - fitted from your ceiling
 - Outside reveal (on wall - overlapping the window)
- with curtains it always best to measure wall to wall for a more complete and warm look.

Ripple Shade Curtains

Overlapping Door Only

- Measure the width of the door first in millimeters,
- Measure the top section as you see in image,
- Add anything from 300mm to 600mm (it is your choice) to your width size.
- Measure the height,
- Measure the middle part of the window
- Deduct 10mm off the height (we deduct 10mm off the height so the fabric does not touch the floor - but it is your choice if you would like to touch).
- Submit the sizes on the Order Page

Ceiling Top Fix fitting:

- Measure the width and then the height - deduct 10mm from the width and height for fitting space.

Example:

Slight over lapping measurement: 2500 x 2200 (ADDED 500MM TO WIDTH & 100MM TO HEIGHT)

Ceiling Top Fix measurement - 4390 x 2390 (DEDUCTED 10MM FROM WIDTH AND HEIGHT FOR FULL WALL FITTING)

