

# Roller Filter, Screen & Blockout Installation Guide

Buy  
My  
Blinds  
Online.co.za

## Inside Fitting

### Before You Start

Unpack the roller blind/s being very careful not to damage the blind/s or chain when cutting through the packaging. Unwrap the plastic that is protecting your blinds. Included with your blind/s are the following parts: System 40 brackets, Gold Screws, Fischer Plugs, Child Safety chain tie back.

### Step 1

Make yourself familiar with your roller blind. On the control side you will have a slide in slot, with a hook. On the other side you will have the spring operating pin. You will see that the shape of the hook and pin is exact of the set of brackets you received. Make sure you know what side your material roll is - front roll or waterfall roll - rolls from the front, covering the tube. Standard roll is where the material rolls from the back.



Above: Control side - hook look in middle



Above: Spring pin side

### Step 2

Take your blind in hold it in your window area to make sure it fits. the side should almost just touch the wall, this means that there is enough space to fill those sides with the blind brackets.

### Step 3

Take a bracket, and hold it in the middle side edge of your wall recess as per image below. Take a pencil and mark the two outer holes where you will be drilling and be fixing the screws to secure the bracket to the wall. Do the same on other side.



### Step 4

Take a drill with a 6mm drill bit and drill where you marked with th pencil.

### Step 5

After the drilling, insert the Fischer plugs, then hold up the bracket into position and insert each gold screw where you drilled. Take a phillips screw driver and tighten each screw. TIP: it is always best to use electric drills/screwdrivers for this part.

### Step 6

Once the brackets are fixed, test them by pulling them slightly down. if they seem to be a bit loose, remove the screws and secure them again. This is very important for you do not want your blind to come down at any stage.

### Step 7

Clicking your blind in. Hold your blind nice and lever with your recess wall, start with the control side first. With the blind still rolled up, hook the control side into the bracket until you see the blind slides into place. With that step being complete, hold the blind level and with your finger, push in the pin back into the tube. The allows the blind to slide into position. Once flush with the bracket and in position, remove finger, position a bit until you hear a click meaning the cross shaped pin clicked perfectly into place.



Above: Control side hooks in



Above: Pin side clicks in position

### Step 8

Test that the blind is secure, slightly pull down on the blind. The blind should be secured.

### Step 9

Lastly secure the child safety chain tie back to the side where the chain loops - Optional.

### Step 10

Congratulate yourself! you have now installed your own blind, with the above steps you now have a premium custom made blind with a full 2 year warranty. Now tell your friends about us, and we will be waiting for your next order.

Thank you

Team BuyMyBlindsOnline.co.za  
011 868 1546

part of the GalaxyBlinds group